Eye-Guided Mouse Control The Future Of User Interface

• Execution Sequence

To run this code in PyCharm, you will need to install the following packages:

- 1. OpenCV: You can install OpenCV by running 'pip install opency-python' in your terminal or PyCharm's terminal.
- 2. Mediapipe: You can install Mediapipe by 'running pip install mediapipe' in your terminal or PyCharm's terminal.
- 3. PyAutoGUI: You can install PyAutoGUI by running 'pip install pyautogui' in your terminal or PyCharm's terminal.
- 4. Here are the steps to execute the code in PyCharm:
- 5. Open PyCharm and create a new Python project.
- 6. Create a new Python file in the project and paste the code into the file.
- 7. Install the required packages by running the pip install commands mentioned above in your PyCharm's terminal.
- 8. Write the Python code for Eye-Guided Mouse Control The Future Of User Interface
- 9. Make sure your webcam is connected and working properly.
- 10.Run the Python file by clicking on the green arrow button on the top right corner of the code editor or by pressing the Shift+F10 key.
- 11. You should now see a window titled "Eye-Guided Mouse Control" with a live video feed from your webcam. If the code is detecting your eye movements, you should see green and yellow circles drawn around your eye landmarks.
- 12. To exit the code, press any key on your keyboard.

12. Note: Packages Versions

Numpy - 1.13.3

OpenCV - 3.2.0

PyAutoGUI - 0.9.36

Source Code

```
import cv2
import mediapipe as mp
import pyautogui
cam = cv2.VideoCapture(0)
face_mesh = mp.solutions.face_mesh.FaceMesh(refine_landmarks=True)
screen_w, screen_h = pyautogui.size()
while True:
    , frame = cam.read()
    frame = cv2.flip(frame, 1)
    rgb frame = cv2.cvtColor(frame, cv2.COLOR BGR2RGB)
    output = face_mesh.process(rgb_frame)
    landmark_points = output.multi_face_landmarks
    frame_h, frame_w, _ = frame.shape
    if landmark points:
        landmarks = landmark_points[0].landmark
        for id, landmark in enumerate(landmarks[474:478]):
            x = int(landmark.x * frame_w)
            y = int(landmark.y * frame h)
            cv2.circle(frame, (x, y), 3, (0, 255, 0))
            if id == 1:
                screen x = screen w * landmark.x
                screen y = screen h * landmark.y
                pyautogui.moveTo(screen x, screen y)
        left = [landmarks[145], landmarks[159]]
        for landmark in left:
            x = int(landmark.x * frame_w)
            y = int(landmark.y * frame h)
            cv2.circle(frame, (x, y), 3, (0, 255, 255))
        if (left[0].y - left[1].y) < 0.004:
            pyautogui.click()
            pyautogui.sleep(1)
    cv2.imshow('Eye Controlled Mouse', frame)
    cv2.waitKey(1)
```